



## Multi-Mount monitor



### Article-No. Description

EP0205022 Multi-Mount monitor

EP0205023 Alarm sensor for Multi-Mount monitor

Permanent workstation monitor with a multitude of functions for a single-workstation. The monitor permanently observes the correct grounding of the wrist strap and the ESD-workstation. Should either connection accidentally be disconnected (wrist strap is being taken off or the ground connection to the table mat ripped off) a acoustic and visual alarm will sound.

The patented „Wave-Distortion technology“ allows save and permanent monitoring, while other systems only check in interval. If the worker is leaving the workstation the wrist strap can be „parked“ at special connection point, not sounding an alarm.

### Characteristics:

- Improved alarm, adjustable quiet/loud
- External alarm sensor optionally available
- For areas without table mats the monitoring function can be deactivated

### External alarm sensor for Multi-Mount monitor (EP0205022)

- Alarm sensor
- Connection to Multi-Mount monitor
- Fastening screws
- Double sided tape pad

## Permanent monitoring system



### Double station for 2 workstations

Permanent monitoring of wrist straps, table mats or table top

- Real time monitoring through „Wave Distortion technology“
- Acoustic and visual alarm when an error occurs
- Calibrated according to european standards
- Connection style: Grounding cable DK 4 / 10 mm (park= DK 4 mm )
- Grounded through power supply

### Article-No. Description

EP0205002 Double station, park connection 10 mm

EP0205003 Double station, park connection 4 mm

## Calibration unit



Checks testing parameters of permanent monitors (Wave Distortion) without having to remove them from the workstations. Extruded aluminium housing to protect the unit from any electrical interference.

### Also available as rental

More information in our webshop

### Article-No. Description

EP0205024 Calibration unit for permanent monitoring systems