Specialty accessories and software

Get more out of your test tool



to a PC.

FlukeView® Forms

Harness the power of the data logging function on your Fluke Digital Multimeter,

Thermometer or ProcessMeter. Log live

your Fluke 289, 789 or 54-II in place to

readings while connected to a PC, or leave

capture up to 1,000 readings for download



Stray voltage

Eliminates stray voltage due to capacitance between wires in electrical installations

Pressure and vacuum

PV350 Pressure

Vacuum Module · Digital pressure and vacuum measurements in a single module Measures

> HVAC/R, hydraulic and pneumatic pressures to 350 psig/2413 kPa (usable to 500 psig)

microns of vacuum)

Compatible with all instruments and test leads that accept standard 4 mm shrouded banana connectors

Measures to 760 mmHg (29.9 in Hg) vacuum (not intended for measuring

Compatible with most digital multimeters



Fluke Connect®

ir3000 FC Connector

- Get all the benefits of the Fluke Connect app, and be on the same
- Wirelessly share measurements with your team anywhere, anytime
- Connect the Fluke 289/287 True-rms Logging Multimeter and the 789 ProcessMeter with the ir3000 FC Connector



Fluke Connect® Wireless SD Card

Wirelessly enable your Fluke TiX1000, TiX660, or TiX640 infrared camera with the Fluke Connect wireless SD card. Instantly upload, share and analyze data with anyone on your team. The Fluke Connect WiFi SD Card is included with compatible models, but is shipped separately due to country restrictions.

page, even while in different places



Choose the model that's right for you:

- FVF-SC2: Includes software and cable used with 280 Series DMMs and 789 ProcessMeters, and the 1550 and C/1555 Insulation Tester
- FVF-SC3: Includes software and cable used with 45 Bench Meters
- FVF-SC4: Includes software and cable used with 8845A and 8846A Multimeters

Go to www.fluke.com/flukeviewforms to download the demo.

Fuse selection guide

Replacement fuses for Fluke DMMs are available from your distributor. To order direct from Fluke call 1-800-44-FLUKE (U.S.) or email fluke-info@fluke.com.

Model	Fuse Requirements
21-Ш/75-Ш/73-Ш	P/N 871173 630 mA 250 V fuse P/N 803293 11 A 1000 V fuse
27 (S/N<7247001)	P/N 871173 630 mA 250 V fuse P/N 871202 3 A 600 V fuse P/N 892583 15 A 600 V fuse
27 (S/N>7247001	P/N 943121 440 mA 1000 V fuse P/N 803293 11 A 1000 V fuse
83/85/87 (S/N>6565000)	P/N 943121 440 mA 1000 V fuse P/N 803293 11 A 1000 V fuse
83-III/85-III/87-III 87-IV/89-IV/187/189/287/289/ 77-III/79-III/23-III/26-III/175/177/179/77-IV/27-II/28-II	P/N 943121 440 mA 1000 V fuse P/N 803293 11 A 1000 V fuse
111/112/115/117/233	P/N 803293 11 A 1000 V fuse
1577/1587	P/N 943121 440 mA 1000 V fuse
1503/1507	P/N 2279339 315 mA 1000 V fuse
787/789	P/N 943121 440 mA 1000 V fuse (Qty 2)

Selection Guide	110/111/112	114/115/116/117	27 11/28 11/27	175/177	179	80 Series III/83V	VI 68/78	87V	233	287/289/187/189	43B	120 Series	190 Series	51/52/53/54 П	705/707	715	725/726	741/743	744	187/189	1587 FC	1577
TPAK	•	•		•	•	83V	•	•	•	•				•			•			789	•	•
PV350 (pressure)		•	•	•	•			•	•	•	•	•	•		•	•		•	•	•	•	•
FOM (fiber optic)		•	•	•	•	•	•	•	•	•	•	•	•		•	•		•	•	•		

Model	Instrument compatibility	Cable
FVF-BASIC	Fluke 280 Series, 789, 1550B, 1653, 180 Series	USB/IR
FVF-SC2	Fluke 280 Series, 789, 1550B, 1653, 180 Series	USB/IR
FVF-SC4	Fluke 8808A, 8845A, 8846A, 45*	USB/Serial
IR189USB	USB cable for Fluke-18X, 28X DMMs	USB/IR

FlukeView® Forms Basic

An abridged version of FlukeView Forms.

- Available for use with 280 Series DMMs and 789 ProcessMeters, only
- · Upgrade to the full FlukeView Forms with FVF-UG
- · Compatible with the 280 and 789 series only

Choose the model that's right for you:

- FVF-Basic: FlukeView Forms Basic transfers data from Fluke test tool to a PC. Displays readings in table or graphical format
- FVF-SC2, -SC4: FlukeView Forms Full provides Basic software functions plus customizable documents and templates
- FVF-UG: FlukeView Forms Upgrade, compatible with all forms of FlukeView Forms (Basic and Full)